

Using FS10 Video System for Balint Intensives

Contents of briefcase

1. FS10 Cameras, power cord and wireless remote (x2)



2. Tripod



3. Microphone



4. Microphone phantom power supply



5. XLR Extension Cable



6. Beachtek DXA25 XLR Adapter



7. TV Connection cord (x2)



8. USB computer connection (only needed to copy video files to computer and should not be needed for Balint Intensives)



Instructions

1. Connect Beachtek DXA25 Adapter (#6) to Camera (#1)
Note that a coin will be needed to turn screw
It's wise to use the camera power cord (in #1) or you may run out of juice before the group is finished. There is a white extension cord in the kit that will likely be needed.
2. Connect Beachtek DXA 25 to tripod (#2)
3. XLR extension cable (#5) connects to front of DXA25 – be aware that the side you've plugged the cable in to on the DXA25 is the side on which you'll need to make knob adjustments on the back. Note color coding on XLR Cable
4. Plug XLR cable into Phantom Power Supply box, (#4) and make sure that the phantom power supply power cord is plugged in.
5. Plug microphone (#3) into Phantom Power Supply box. When box is plugged into electricity appropriately, green light on top of mike lights up.
6. Short pigtail cord on front of DXA25 (#6) should plug into Microphone input on left side of camera.
7. Turn on camera. Set camera function for recording. Press record button when Balint Group begins. Stop when Group is over. Detach first camera from DXA25 and leave with Group. Attach second camera in same way to use with second Balint group.
8. Group 1 can review their video by plugging the camera directly into a room TV using TV Connection Cord (#7) and wireless remote. Note that wireless remote is matched to camera with color sticker (blue or red)

Good luck and have fun at your intensive.

John Muench
muenchj@ohsu.edu
w: 503 494-3437
h: 503 771-4264